

POWER HEAD (7.5 HP)

1. Cylinder head screw
 2. Plain washer
 3. Spark plug
 4. Cylinder head
 5. Head gasket
 6. Cylinder and crankcase cover assembly
 7. Drain cover gasket
 8. Drain screen
 9. Drain cover
 10. Screw
 11. Locating pin
 12. Piston rings
 13. Piston pin retainer
 14. Piston pin
 15. Piston
 16. Connecting rod
 17. Bearing cage
 18. Roller bearings
 19. Center main roller bearings
 20. Center main bearing liner
 21. Crankshaft seal
 22. Connecting rod screw
 23. Lower crankshaft seal
 24. Lower main bearing
 25. Crankshaft and upper main bearing assembly
 26. Exhaust plate gasket
 27. Exhaust plate
 28. Exhaust cover
 29. Screw
 30. Screw
 31. Screw
 32. Screw
 33. Screw
 34. Stator ring
 35. Bearing cage gasket
 36. Bearing cage
 37. Upper crankshaft seal
 38. Screw
 39. Crankshaft spline seal
 40. Cylinder mounting gasket
 41. Woodruff key
-