


POWER HEAD COMPONENTS (3 HP ONE-CYLINDER MODEL)



1. Piston
2. Lockring
3. Piston pin
4. Piston pin bearing
5. Crankshaft and connecting rod assembly
6. Main bearing
7. Spacer
8. Crankshaft seal
9. Cylinder block/crankcase cover
10. Head gasket
11. Cylinder head
12. Water jacket cover
13. Gasket
14. Bolt
15. Bolt
16. Exhaust tube
17. Piston rings
18. Thermostat
19. Gasket
20. Thermostat cover