


CRANKSHAFT, PISTON AND CONNECTING ROD ASSEMBLY (4 DELUXE, 3 AND 4 HP)



1. Crankshaft seal
2. Needle bearing
3. Crankshaft
4. Flywheel key
5. Bearing assembly
6. Seal ring
7. Ball bearing
8. Bearing retainer
9. Crankshaft retainer
10. Crankshaft seal

11. Bearing assembly
12. Connecting rod cap
13. Connecting rod
14. Thrust washer
15. Needle bearing
16. Piston
17. Piston pin
18. Piston pin retainer
19. Piston rings