

# CRANKSHAFT, PISTON, CONNECTING ROD AND RELATED COMPONENTS (V6 LOOP CHARGED MODELS)

1. Seal
2. Upper crankcase head
3. O-rings
4. Crankshaft seal ring
5. Flywheel key
6. Crankshaft
7. Main bearing liner
8. Main bearing half
9. Retaining ring
10. Connecting rod cap
11. Connecting rod bearing half
12. Connecting rod
13. Thrust washer
14. Piston pin retaining ring
15. Piston rings
16. Piston
17. Piston pin
18. Piston pin bearing assembly
19. O-rings
20. Lower main bearing retaining plate
21. Lower main bearing
22. Snap ring
23. O-ring
24. Crankshaft sleeve
25. Seal
26. Lower crankcase head

