

1. Water tube seal
2. Seal
3. Water pump disc
4. Screw
5. Water pump cover
6. Water pump body
7. Impeller
8. Plate
9. Seal
10. Drive shaft upper bearing
11. Screen
12. Intermediate shift rod
13. Lower shift rod seal
14. Upper gearcase housing
15. Plug
16. Gasket
17. Exhaust snout (anode)
18. Screw
19. Screw
20. Seal
21. Nut
22. Lockwasher
23. Stud
24. Shift rod pin
25. Cotter pin
26. Lower shift rod
27. Shift arm
28. Pinion gear and bearing assembly
29. Stud
30. Lockwasher
31. Nut
32. Shift arm pivot pin
33. Seal
34. Lower gearcase housing
35. Forward gear and bearing assembly
36. Thrust washer
37. Clutch
38. Shift yoke
39. Roll pin
40. Shift arm pin
41. Propeller shaft
42. Ball
43. Thrust washer
44. Reverse gear
45. O-ring
46. Propeller shaft bearing
47. Propeller shaft seal
48. Bearing cage
49. Screw
50. Propeller
51. Propeller drive pin
52. Propeller nut seal
53. Propeller nut
54. Cotter pin
55. Drive shaft boot
56. Retainer
57. Drive shaft
58. Impeller drive pin
59. Water tube (long shaft models)
60. Washer
61. Seal