

DRIVE SHAFT AND WATER PUMP COMPONENTS (200 HP OPTIMAX, 225 HP AND 250 HP MODELS)

1. Water tube guide
 2. O-rings
 3. Centrifugal slinger seal
 4. Pump housing
 5. Screw
 6. Impeller
 7. Impeller key
 8. Gaskets
 9. Plate
 10. Seal carrier
 11. O-ring
 12. Upper drive shaft seal
 13. Lower drive shaft seal
 14. Drive shaft bearing retainer
 15. Roller bearing assembly
 16. Shim pack
 17. Drive shaft
 18. Drive shaft coupler*
 19. Upper drive shaft*
 20. Water dam seal
 21. Vent plug and seal
 22. Screw
 23. Anodes
 24. Locknut
 25. Dowel pins
 26. Speedometer tube and fittings
 27. Shift shaft
 28. Washer
 29. Shift shaft seal
 30. Shift shaft retainer/bushing
 31. O-rings
 32. Retainer screw
 33. Drain/fill plug and sealing washer
 34. Lower drive shaft roller bearing
 35. Pinion gear
 36. Washer
 37. Pinion nut
 38. Pivot pin
 39. Gearcase housing
- *Not used on all models

