


**CYLINDER HEAD, WATER JACKET, EXHAUST COVER AND THERMOSTAT
(DT75 AND DT85 MODELS)**



1. Cylinder block
2. Crankcase cover
3. Thermostat cover gasket
4. Cylinder head
5. Water jacket cover
6. Thermostat cover
7. Thermostat
8. Lifting hook
9. Exhaust cover
10. Exhaust cover gasket
11. Water jacket cover gasket
12. Cylinder head gasket