

GEARCASE (DT115 AND DT140 MODELS)

- | | | |
|------------------------------------|--|---------------------|
| 1. Shim | 22. Thrust washer | 43. Bolt |
| 2. Bearing race | 23. Thrust washer | 44. Nut and washer |
| 3. Bearing | 24. Propeller shaft | 45. Cover |
| 4. Drive shaft | 25. Cross pin | 46. Bracket |
| 5. Pin | 26. Spring | 47. Plate |
| 6. Preload spring | 27. Clutch spring | 48. Bolt |
| 7. Sleeve | 28. Clutch | 49. Anode |
| 8. Thrust washer | 29. Follower | 50. Water tube |
| 9. Tabbed thrust washer | 30. Thrust washer | 51. Plug |
| 10. Pinion gear | 31. Front mounted gear
(forward gear) | 52. Plate |
| 11. Pinion nut | 32. Bearing | 53. Grommet |
| 12. Bolt | 33. Bearing race | 54. Bracket |
| 13. Lockwasher | 34. Shim | 55. Plate |
| 14. Locking clip | 35. Bearing | 56. Cover |
| 15. Seal | 36. Bearing assembly | 57. Plug |
| 16. Bearing | 37. Alignment pin | 58. Plate |
| 17. Bearing carrier | 38. Bearing | 59. Bolt |
| 18. O-ring | 39. Plug | 60. Trim tab |
| 19. Bearing | 40. Plug | 61. Water screen |
| 20. Shim | 41. Screw | 62. Washer |
| 21. Rear mounted
gear (reverse) | 42. Water screen | 63. Drain/fill plug |

